




AC500eCo
RS485 COM1

CP400
RS485



- Functional Earth
- Protective Ground
- SGND Signal Ground
- RS485 TxD/RxD-P**
- n.c.
- SGND Signal Ground
- +3,3 V out
- n.c.
- RS485 TxD/RxD-N**
- n.c.



- Functional Earth
- RS485+**
- RxD Receive Data
- TxD Transmit Data
- n.c.
- SGND Signal Ground
- RS485-**
- RTS Request To Send
- CTS Clear To Send
- +5V@100mA output