


only on CP554 & CP552
via Plug-In Block
RS485



AC500-eCo
via COM1
RS485



AC500-eCo
via COM2
RS485




RS485 RxD/TxD-P


RS485 RxD/TxD-N

SGND Signal Ground

Functional Earth



Functional Earth



1 Terminator P

2 RS485 RxD/TxD-P

3 RS485 RxD/TxD-N

4 Terminator N

5 Functional earth



Artikelnummer:

Datum
08-03-2013

Schaal
N.v.t.

Klant

AC500eco CP500

AC500 eco RS485

Solar T.P.S.

Versie
A

Pagina
1 of 1